



8020 SERIES WIRING DIAGRAM

WARNING

MUST USE PC - 91 COIL
OR A COIL WITH A PRIMARY
RESISTANCE OF 0.5 TO 1.0 OHMS
(E.G. BOSCH 716 OR 717)

USE OF ANY HIGHER RESISTANCE COIL
WILL DAMAGE THE UNIT

THIS UNIT REQUIRES 12 VOLTS TO RUN
ALL RESISTORS AND RESISTANCE WIRES
MUST BE REMOVED OR BYPASSED

FAILURE TO COMPLY WITH ANY OF
THESE CONDITIONS

WILL VOID WARRANTY

